



BASIC CAMPERVAN ELECTRICALS

Recommendations: 16mm² Cable for Anderson plugs, suitably sized circuit protection including Circuit Breakers & Fuses, secure cables with Sikaflex or Silicon adhesive at spot points to prevent vibration rub, ensure battery is well secured and in a Battery Box, solder all connections, Insulate exposed cables, adopt Floating Earth system for all Earths (all earths return to battery -), Keep cables high in camper to prevent catching on sticks etc, recommend Engle fittings for all fridge DC power connections to prevent separation.